

Quick Reference Guide



VP**800**Android POS



Transactions

CREDIT SALE

- 1. Enter Transaction Amount and tap Enter.
- 2. Swipe/Insert/Tap card on Present Card screen. For Manual Key Entry, select the Enter Manually option.
- 3. Sign and Tip if prompted.
- 4. Select receipt delivery method.

DEBIT SALE

- Tap Credit until Debit is displayed.
- 2. Enter Transaction Amount and tap Enter.
- Swipe/Insert/Tap card on Present Card screen.
 For Manual Key Entry, select the Enter Manually option.
- 4. Enter PIN and Tip if prompted.
- Follow prompts until receipt prompt-select receipt delivery method.

CREDIT VOID

- 1. Tap Sale until Void is displayed.
- Enter the Transaction Number from the receipt or the last 4 of the card number and tap Enter.
- 3. When prompted enter Password.
- 4. Tap to confirm the transaction that needs to be voided.
- 5. Select receipt delivery method.

CREDIT REFUND

- Tap Sale until Refund is displayed.
- 2. Enter Transaction Amount and tap Enter.
- 3. Swipe/Insert/Tap card on Present Card screen.
 For Manual Key Entry, select the Enter Manually option.
- 4. Select receipt delivery method.

CREDIT PREAUTH

- 1. Tap Sale until Preauth is displayed.
- 2. Enter Transaction Amount and tap Enter.
- Swipe/Insert/Tap card on Present Card screen. For Manual Key Entry, select the Enter Manually option.
- Select receipt delivery method.

CAPTURE PREAUTH

- 1. Tap Sale until Ticket is displayed.
- Enter Transaction Amount, tap Enter and enter Password.
- 3. Enter the **Transaction Number** from the receipt or the **last 4 of the card number** and tap **Enter.**
- 4. Sign and Tip if prompted.
- 5. Select receipt delivery method.

PRE-SALE TICKET

- 1. Tap the Main Menu icon and select Pre Sale.
- Enter the Transaction Amount, press the Enter Button and the pre-sale ticket will be printed.



Main Menu Options

TRANSACTIONS

Overview of Transactions posted on Selected Date

PRE SALE

Create a Pre Sale Ticket

SETTLEMENT

Perform a Batch Settlement

UPDATES

Perform a Parameter or Application Download on Terminal

PAYMENT

Perform Multiple Payment Types

REPORTS

View Different Report Types

TIP ADJUST

Perform Tip Adjust on Open Batch Transactions

REPRINT RECEIPT

Reprint Last Transaction's Receipt

REPRINT

Reprint Previous Transaction Receipts

SETTINGS

Configure Device Settings including WIFI, SIM, Passwords, etc.



Connect to WiFi

- 1. From the Home Screen, tap the Main Menu icon.
- 2. Tap Settings, then WiFi Config
- 3. Tap SSID
- 4. Enter WiFi Password (Password is case sensitive)
- 5. Tap Connect

Terminal Guide



1.Connection Icon

2.Battery Level

3.Main Menu

4. Inventory

Contact Support

Visit our website to learn more!

Scan the QR Code with your mobile device for more information on this and Magnify Payments.







(1-800-528-8694